

Maintenance Checklist CP-6 – CP-12

# from Nomenclature Drawing	Item	Every Shift	Monthly	As needed	Annually
1	Motor - Check for any blockage of fan from dust			X	X
2	Gearbox Adapter - replace autolube if so equipped				X
3	Gearbox - Test oil. Change if needed.				X
4	Seal Plate Assembly - Lubricate one shot of grease		X		
4	Seal Plate Assembly - Look for leakage	X		X	
6	Screw - Based on abrasiveness of product and history, inspect for wear at discharge			X	X
8	Screen - Based on abrasiveness of product and history, inspect for wear at discharge			X	X
11	Cone Bushings - Inspect for wear or deformation				X
15	Flange Bearing – Check temperature and radial runout. Lubricate with grease.		X (Temp/ Runout)		X (Grease)
16	Air Cylinders - Inspect connections and look for leakage			X	X
17	4-Way Valve - Check air line connections and ease of movement				X
18	Air Regulator - Check air line connections. If equipped with lubricator, fill with oil.				X